Your international partner www.trexrubber.com





PERMAFLEX STARTER KIT QUICK START

- √ The material cures to ready for touch in 2 minutes.
- The repair area can be buffed in 30 minutes.
- 100% solids and no Volatile Organic Compounds (VOC).
- Maximum hardness of 60 Shore A.
- A rapid and permanent flexible repair.
- ✓ Can be used as repair for conveyor belts, drum lagging or lining.











Buff the repair area.



Apply the primer.



Remove seal cap.



Screw on static mixer.





Insert cartridge into application tool. Apply Permaflex repair material.



Use 750 cartridge for large area repairs.



Level with spatula if needed.



Buff repair area after 30 minutes.